
Cozy Aroma Diffuser User Manual





ABOUT

The Cozy Aroma Diffuser's elegant design integrates beautifully in any interior. The essential oil diffuser is made of high quality and safe material, provides a stable and accurate fragrance and works very silently. Its USB rechargeable battery allows you to create a relaxing and soothing environment in any room of your home.

SAFETY INSTRUCTIONS

- Read this manual in detail before using the device. Keep the manual for future reference.
- Do not use damaged power sockets, cables or power adapters. It may endanger your safety and cause a fire, please replace in time if it happens.
- The device does not contain any user-serviceable parts. Do not modify, disassemble or repair the device yourself.
- Oil leakage may damage the device. Do not invert or tilt the device when in use. Clean the device and empty any remaining oil before transporting it.
- Maintain and clean the device regularly to ensure the device in best working states. See the section Maintenance below.

TECHNICAL SPECIFICATIONS

Dimensions	Ф154 x 146 mm
Package Dimensions	195 x 195 x 235 mm (width x depth x height)
Canister Capacity	150 ml
Net weight	1.20 kg
Coverage	50 m²
Voltage	Type-C 5V-1A
Power	2.5W
Noise	≤ 38 db

ACCESSORIES

Item	Power cable	User manual
Diagram	6	Light reacted



INSTALLATION



TOUCH PANEL DESCRIPTION



White transparent touch indicator

FILLING THE DIFFUSER

- 1 Make sure the device is switched off.
- (2) Rotate the bottle counter-clockwise and lift it from the diffuser.
- ③ Fill the bottle with essential oil (maximum 150 ml).
- 4 Align the bottle and the diffuser with the direction of the air outlet and install them into the device.

OPERATING INSTRUCTIONS

- ① Connect the power cord to the included power adapter.
- ② Plug the power cord into the USB-C port on the device.
- ③ Plug the power adapter into the power socket.
- (4) The device switches on in standby mode (the power indicator light turns on and off).
- (5) You can also connect the device to a computer using the included cable.



OPERATION

Press the power button to switch on the device.

The device has 3 working modes (low - normal - high).

- Press the button once to set the working mode to low.
- Press the button once to set the working mode to normal.
- Press the button once to set the working mode to high.

Working mode	Activity / Pause
low	60 seconds / 300 seconds
normal	60 seconds / 180 seconds
high	60 seconds / 60 seconds

MAINTENANCE

Cleaning frequency depends on operating frequency. To ensure optimal operation of your device, check and maintain the device:

- at least every six months
- when using a new fragrance
- when the diffuser volume weakens

To clean the canister:

- (1) Remove the oil canister from the device.
- (2) Poor a little industrial alcohol into the canister and clean it.
- ③ When done, poor a little alcohol into the canister and install it on the device.
- (4) Switch on the device and set it to operate for 5 to 8 minutes.
- ⑤ Turn off the device when finishing cleaning.

To clean the casing:

- Use a soft cloth to clean the outside casing.
- Do not immerse the device in any liquid.

DISPOSAL

Do not dispose of the unit (or batteries) as unsorted municipal waste; This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules.

